



Historian User Guide

Written By: Alejandro Pagán Albertos

Login

Password


Sign In

EN DE

INTRODUCTION

This is depreciated version of the guide - please refer to latest version [HERE](#)

Step 1 — Historian User Guide



Login


Password

Sign In

EN DE

- Insert LOGIN and PASSWORD

Step 2



HISTORIAN... turn data into information

DEMO DATA SET

DATA ACCESS ALARM MANAGEMENT ANALYSIS TOOLS SIGN IN EN DE ?

DATA FROM DATA TO INTERVAL STEP AGGREGATION

month per hour 1 TXP Display JointDisplay PointsChart Export Groups

Only limited sample data in this demo. Don't know where to start? Try March 2013 ...



KKS / DESCRIPTION RANGE Remove all

Add signal

Pick signal first using the "Add Signal" button.


- To search for signal data, click Add signals button

Step 3




- Select the type of signal you want to search for.
- Select *SEARCH*

Step 4




- Once you have the signal, you can choose the ones you want by clicking on *SELECT*
- ☑ You can select the signals that remain.

Step 5



- i** After finding requested signals the users should specify the point of view they are requesting.
- DATA FROM – start of the requested data range
 - DATA TO – end of the requested data range. May be specified either relatively (day, week, month, quarter, half-year, year, two years or ten years) or absolutely (value custom)
 - INTERVAL – represents the aggregation interval (one value per second/minute/hour/day) or raw data
 - STEP – aggregation step (usually 1 which means one value per one hour, etc.)
 - AGGREGATION – aggregation method (OPC aggregation method such as Interpolative, Average, etc.) or TXP aggregation which should correspond to the aggregation method of the original system
 - Cuando estén todos los datos, haremos click en DISPLAY


Step 6



i Once the point of view is specified, users may show charts with signal values.

- Display – shows separate chart for each signal
- JointDisplay – show one chart containing all selected signals as separate series
- PointsChart – available only if exactly two signals are selected – the values of signals are used as axis points.

Step 7



i Charts allow additional user interactions – user may:

- Browse through the previous/following time intervals using the left/right arrows
- Download chart as a PNG image
- Configure various aspects of the chart (series colors, axis) or zoom time range series using quick sliders
- Zoom chart to the whole screen

Step 8

HISTORIAN... turn data into information

DATA ACCESS | ALARM MANAGEMENT | ANALYSIS TOOLS | SIGN IN

DATA FROM: month | DATA TO: per hour | INTERVAL: 1 | STEP: TXP | AGGREGATION: Display | JointDisplay | PointsChart | Export | Groups

Only limited sample data in this demo. Don't know where to start? Try March 2013 ...

KKS / DESCRIPTION	RANGE	Remove all
00CXM01CP001A_XQ01 [A1] - ENVMT AIR PRES	800-1060 mbar	Remove
00CXM01CP001A_XQ01 [A1] - ENVMT AIR PRES	800-1060 mbar	Remove

Add signal

00CXM01CP001A_XQ01 [A1]

IKZ: 0x0001.6.75.0[61.1].109.-1

Template info:

ENVMT AIR PRES
800-1060

Additional info

Instrumentation and control equipment (Organization according to I&C functions)
Local control stations (e. g. for solid fuel supply system, ash removal system, cooling water system, diesel engine plant, monitoring of generator cooling, emergency control)
Local control station
Direct measuring circuits
Pressure
Analog signals
[Full Detail](#)

- There is a small icon next to the KKS sign that shows information in small

Step 9

HISTORIAN... turn data into information

DATA ACCESS | ALARM MANAGEMENT | ANALYSIS TOOLS | SIGN IN

00CXM01CP001A_XQ01 [A1]

IKZ: 0x0001.6.75.0[61.1].109.-1

Template info:

ENVMT AIR PRES
800-1060

Additional info

Instrumentation and control equipment (Organization according to I&C functions)
Local control stations (e. g. for solid fuel supply system, ash removal system, cooling water system, diesel engine plant, monitoring of generator cooling, emergency control)
Local control station
Direct measuring circuits
Pressure
Analog signals
[Full Detail](#)

HISTORIAN... turn data into information

DATA ACCESS | ALARM MANAGEMENT | ANALYSIS TOOLS | SIGN IN | DEMO DATA SET

00CXM01CP001A_XQ01

IKZ: 0x0001.6.75.0[61.1].109.-1

Cabinet

10CP091

Rack

109

Description



A1 ENVMT AIR PRES
800-1060 mbar
Total events ccs: 63715667


Additional info

Instrumentation and control equipment (Organization according to I&C functions)
Local control stations (e. g. for solid fuel supply system, ash removal system, cooling water system, diesel engine plant, monitoring of generator cooling, emergency control)
Local control station
Direct measuring circuits
Pressure
Analog signals

- Also shows full detail of the signal

Step 10






 Signal data may be exported either for one signal or for all signals at once.

- Click Export
- Exact time can be specified in the Export dialog (using hour, minutes and seconds) as well as export format (CSV or XLS).

 Joint export is not available for exporting raw data (as there is no way to pair particular values)

Step 11



 Users can save the list of frequently used signals in the so-called Group and can be private or public

- Select GROUPS and SAVE AS
- Enter group name
- Select private or not

 Once the group is saved, user may get back to the list at any time by simply opening the group.

Step 12

HISTORIAN

turn data into information

DEMO DATA SET

DATA ACCESS

ALARM MANAGEMENT

ANALYSIS TOOLS

SIGN IN

EN DE ?

Range: Minute Before: 08/08/2015 06:00:02

Page Size: 25 Event types: A C D E F I O S T W Unit: System: Equipment:

Signal: Description:

Show Aggregations Total 40 records Don't know where to start? Try March 2013 ...

TIMESTAMP	SIGNAL	GROUP	DESCRIPTION	STATUS
* 08/08/2015 05:59:02.550	E 11MBY10EP001_SOIHO	G1	EQUIV OP HOURS	Coming
08/08/2015 05:59:03.540	E 11MBY10EP001_SOIHO	G1	EQUIV OP HOURS	[Going]
08/08/2015 05:59:17.154	E 10MAG10AA051A_XBQ2	S1	SOL VLV VACUUM BREAKER	[Going]
08/08/2015 05:59:17.154	E 10MAG10AA051A_XBQ2	S1	SOL VLV VACUUM BREAKER	[Going]
* 08/08/2015 05:59:17.154	E 10MAG10AA051A_SZIAU	S1	SOL VLV VACUUM BREAKER	Coming
08/08/2015 05:59:17.154	E 10MAG10AA051A_SZIAU	S1	SOL VLV VACUUM BREAKER	Coming
* 08/08/2015 05:59:17.554	E 10MAG10AA051A_XBQ2	S1	SOL VLV VACUUM BREAKER	Coming
08/08/2015 05:59:17.554	E 10MAG10AA051A_XBQ2	S1	SOL VLV VACUUM BREAKER	Coming
* 08/08/2015 05:59:17.554	E 10MAG10AA051A_SZIAU	S1	SOL VLV VACUUM BREAKER	[Going]
08/08/2015 05:59:17.554	E 10MAG10AA051A_SZIAU	S1	SOL VLV VACUUM BREAKER	[Going]
* 08/08/2015 05:59:21.540	E 11MBY10EP001_SOIHO	G1	EQUIV OP HOURS	Coming
08/08/2015 05:59:22.550	E 11MBY10EP001_SOIHO	G1	EQUIV OP HOURS	[Going]
08/08/2015 05:59:24.752	E 10MAG10AA051A_XBQ2	S1	SOL VLV VACUUM BREAKER	[Going]
08/08/2015 05:59:24.752	E 10MAG10AA051A_XBQ2	S1	SOL VLV VACUUM BREAKER	[Going]
* 08/08/2015 05:59:24.752	E 10MAG10AA051A_SZIAU	S1	SOL VLV VACUUM BREAKER	Coming
* 08/08/2015 05:59:24.752	E 10MAG10AA051A_SZIAU	S1	SOL VLV VACUUM BREAKER	Coming
* 08/08/2015 05:59:25.152	E 10MAG10AA051A_XBQ2	S1	SOL VLV VACUUM BREAKER	Coming
* 08/08/2015 05:59:25.152	E 10MAG10AA051A_XBQ2	S1	SOL VLV VACUUM BREAKER	Coming

Alarm management serves as a browser page for Sequence of Events (SOE) data.

- Select ALARM MANAGEMENT


Step 13

- The range can be specified either relatively (as a minute/hour/day/week before a timestamp) or absolutely (using custom range between two timestamps).
- The events can be filtered using their event types or by the properties of corresponding signals (eg. Unit/System/Equipment/Signal/Description).

Step 14


- Selected events can be exported into a CSV file by pressing the Export button at the bottom of the page.
- CSV exported

Step 15



● ????

Step 16



i Events quantities provides a quick overview of the complete dataset. The overview represents separate columns for each event types.

- W for warnings
- T for tolerances
- A for alarms
- F for failures
- OE for operator events
- ... for summary of other types of events


Step 17



i Each cell represents a particular time period (day/hour/15min/minute).



- Particular value can be shown by hovering a mouse cursor over the cell.
- Intensity of the color represents the number of events in particular cell

Step 18





- By clicking a cell, particular time range is selected and a detailed view is displayed.
- More detail
- More detail

Step 19



- The view can be filtered with respect to any functional area or their combination.
- For reporting purposes, the view can be also saved as a PNG file using the button with image icon.


Step 20



i Detailed view allows users to precisely analyze the events inside the system, their exact timing, sequences and durations. Each row in this view represents a particular signals which appeared during the selected time range.


- Signals can be reordered (by simple drag and drop on their label)
- Hidden (by pressing the X mark next to the label of selected signal)
- The whole list can be filtered by their type (typically for Alarms, Warnings, Failures, Tolerances, Operator Events) or by their nature (Engineered Signals or DCS Internal Signals)

Step 21




- To have more information click
- Full detail
- Logical Diagram

Step 22



- The view can be zoomed (by dragging the zoom slider on the right top part of the page) or sorted.
- Right bottom part of the page contains a quick preview of the selected time range with all signals at once (to quickly spot important timestamps).
- Detailed view can be saved into a PNG picture by pressing the button with image icon.

Step 23



- ❗ Current state of the page can be saved at any time using so-called Reports.
- Reports are created using the button Save as... and can be either public (all users can see them) or private (only for its creator).

Step 24

USER MANAGEMENT

If the OMLEX Historian application is configured in authorized mode, users are required to sign in prior using the application. Certain users may create new users and grant access to particular application sections. This user management is done through the settings icon on the right part of the menu.

Users

USER	ASSIGNED SECTIONS	AVAILABLE SECTIONS
USER1 (Change Password)	Dashboard (Dashboard), Alarm (Alarms), Settings (Settings), Events (Events), DCS Internal Signals (DCS Internal Signals)	

Create new user:
Name: Password: Create

This page contains a list of existing OMLEX Historian users. The link Change password may be used to set different password for existing user. Second column contains particular sections of the applications which are assigned to this user. The last column contains additional sections, which may be assigned to the user. Section codes are explained in the next table:

Dashboard	Grants access to the OMLEX Historian itself – namely the Data Access and Alarm Management pages.
-----------	--

- ❗ If the OMLEX Historian application is configured in authorized mode, users are required to sign in prior using the application.
- This user management is done through the settings icon on the right part of the menu.